





International Conference on Ion Sources 8th-12th September Oxford



3D sketch of the plasma chambe

multi-disks collimator

Al Tools for Plasma Diagnostics by X-ray Imaging and Spectroscopy in the PANDORA **Project Frame**


B. Peri ^{1,2}, E. Naselli ¹, G. Finocchiaro ¹, A. Pidatella ¹, B. Mishra ¹, D. Santonocito ¹, D. Mascali ¹

¹ INFN – Laboratori Nazionali del Sud, Catania, Italy ² «La Sapienza» University, Roma, Italy

PANDORA PROJECT

Within the PANDORA project (Plasmas for Astrophysics, Nuclear Decays Observation and Radiation for Archaeometry), a novel approach enables the measurement of in-plasma β-decay lifetimes of astrophysical isotopes under stellar-like conditions. This is achieved using a multi-diagnostic system, with a focus on soft X-ray spectroscopy and imaging to characterize the warm electron population (0.5–30 keV).

These diagnostics allow precise monitoring of plasma parameters, offering direct insight into ion source behavior and beam properties, crucial for controlling nuclear decay processes.




State of the Art Single Photon Counting Algorithm


detector:

SPATIALLY-RESOLVED SPECTROSCOPY pixel-by-pixel

- → Decoupling of photon number versus energy
- very short exposure-time (@ 50-500ms)
- thousands of SPhC frames
- → Minimize the pile-up probability
- **→**Cluster Size Filtering:
- Large size (> 5 pixels): multi-photons
- Small size (≤ 5 pixels): single-photon



Experimental Set Up



Lead Pin-hole (diameters 400 µm) Lead multi-disks collimator system

to reduce the scattering noise, increasing resoltution and signal-tonoise ratio

* Improve the energy resolution

Improve the signal to noise ratio

means of the pile-up identification

Employing a Machine Learning Algorithm allows to:

* Minimize the spurious effect contribution, by

Motivation

Furthermore, it will push towards different goals, such as:

Energy resolution: 236 eV @ 8 keV


Space resolution: 500μm

- !dentification of specific patterns
- Online Analysis Options, in order to manage huge amount of datas while measuring

We decided to use an **Hybrid Approach**



State of the art tool for image analysis, based on connectivity it allows to identify and characterize each event, i.e. each photon iminging on the CCD matrix.



ccen	wax	N LOCAI M	Area	ents	Eve
		1	20	1	
	3	3	4	2	

The extracted features play a fundamental role in spurious event identification.

- Area: the number of pixel lighted by each event
- Number of Local Maximum: the presence of more then one local max can highlight a multi-photon event
- Eccentricity: ratio between the major and minor axis of the event interest are

